SECTION EC
ENGINE CONTROL SYSTEM

CONTENTS

INDEX FOR DTC 8
DTC No. Index 8
Alphabetical Index 12
PRECAUTIONS 16
Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER” 16
Precautions for Procedures without Cowl Top Cover 16
On Board Diagnostic (OBD) System of Engine and A/T, CVT 16
Precaution 17
PREPARATION 20
Special Service Tools 20
Commercial Service Tools 21
ENGINE CONTROL SYSTEM 22
System Diagram 22
Multiport Fuel Injection (MFI) System 23
Electronic Ignition (EI) System 25
Fuel Cut Control (at No Load and High Engine Speed) 26
AIR CONDITIONING CUT CONTROL 27
Input/Output Signal Chart 27
System Description 27
AUTOMATIC SPEED CONTROL DEVICE (ASCD) .. 28
System Description 28
Component Description 29
CAN COMMUNICATION 30
System Description 30
EVAPORATIVE EMISSION SYSTEM 31
Description 31
Component Inspection 34
Removal and Installation 35
How to Detect Fuel Vapor Leakage 35
ON BOARD REFUELING VAPOR RECOVERY (ORVR) 38
System Description 38
Diagnostic Procedure 39
Component Inspection 42
POSITIVE CRANKCASE VENTILATION 44
Description 44
Component Inspection 44
NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS) 46
Description 46
ON BOARD DIAGNOSTIC (OBD) SYSTEM 47
Introduction 47
Two Trip Detection Logic 47
Emission-related Diagnostic Information 48
Malfunction Indicator Lamp (MIL) 61
OBD System Operation Chart 65
BASIC SERVICE PROCEDURE 70
Basic Inspection 70
Idle Speed and Ignition Timing Check 75
Procedure After Replacing ECM 77
VIN Registration 77
Accelerator Pedal Released Position Learning 77
Throttle Valve Closed Position Learning 78
Idle Air Volume Learning 78
Fuel Pressure Check 81
TROUBLE DIAGNOSIS 83
Trouble Diagnosis Introduction 83
DTC Inspection Priority Chart 89
Fail-Safe Chart 91
Symptom Matrix Chart 92
Engine Control Component Parts Location 96
Vacuum Hose Drawing 102
Circuit Diagram 103
ECM Harness Connector Terminal Layout 105
ECM Terminals and Reference Value 105
CONSULT-II Function (ENGINE) 113
Generic Scan Tool (GST) Function 126
CONSULT-II Reference Value in Data Monitor 128
Major Sensor Reference Graph in Data Monitor Mode 131
TROUBLE DIAGNOSIS - SPECIFICATION VALUE 133
Description 133
Testing Condition 133
Inspection Procedure 133
Diagnostic Procedure 134

AMOSTRA GRATUITA

automotor.com.br ? Compre o manual completo para acessar todo o conteúdo.

TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT 143
Description 143
Diagnostic Procedure 143
POWER SUPPLY AND GROUND CIRCUIT 144
Wiring Diagram 144
Diagnostic Procedure 145
Ground Inspection 150
DTC U1000, U1001 CAN COMMUNICATION LINE 151
Description 151
On Board Diagnosis Logic 151
DTC Confirmation Procedure 151
Wiring Diagram 152
Diagnostic Procedure 153
DTC U1010 CAN COMMUNICATION 154
Description 154
On Board Diagnosis Logic 154
DTC Confirmation Procedure 154
Diagnostic Procedure 155
DTC P0011 IVT CONTROL 156
Description 156
CONSULT-II Reference Value in Data Monitor Mode 156
On Board Diagnosis Logic 157
DTC Confirmation Procedure 157
Diagnostic Procedure 158
Component Inspection 160
Removal and Installation 160
DTC P0031, P0032, P0051, P0052 HO2S2 HEATER 161
Description 161
CONSULT-II Reference Value in Data Monitor Mode 161
On Board Diagnosis Logic 161
DTC Confirmation Procedure 161
Wiring Diagram 162
Diagnostic Procedure 163
Component Inspection 165
Removal and Installation 165
DTC P0037, P0038 HO2S2 HEATER 166
Description 166
CONSULT-II Reference Value in Data Monitor Mode 166
On Board Diagnosis Logic 166
DTC Confirmation Procedure 167
Wiring Diagram 168
Diagnostic Procedure 170
Component Inspection 172
Removal and Installation 172
DTC P0075 IVT CONTROL SOLENOID VALVE ... 173
Component Description 173
CONSULT-II Reference Value in Data Monitor Mode 173
On Board Diagnosis Logic 173
DTC Confirmation Procedure 173
Wiring Diagram 174
Diagnostic Procedure 176
Component Inspection 177
Removal and Installation 177
DTC P0101 MAF SENSOR 178
Component Description 178
CONSULT-II Reference Value in Data Monitor Mode 178
On Board Diagnosis Logic 178
DTC Confirmation Procedure 178
Overall Function Check 180
Wiring Diagram 181
Diagnostic Procedure 182
Component Inspection 185
Removal and Installation 186
DTC P0102, P0103 MAF SENSOR 187
Component Description 187
CONSULT-II Reference Value in Data Monitor Mode 187
On Board Diagnosis Logic 187
DTC Confirmation Procedure 188
Wiring Diagram 189
Diagnostic Procedure 190
Component Inspection 193
Removal and Installation 194
DTC P0112, P0113 IAT SENSOR 195
Component Description 195
On Board Diagnosis Logic 195
DTC Confirmation Procedure 195
Wiring Diagram 197
Diagnostic Procedure 198
Component Inspection 199
Removal and Installation 199
DTC P0117, P0118 ECT SENSOR 200
Component Description 200
On Board Diagnosis Logic 200
DTC Confirmation Procedure 201
Wiring Diagram 202
Diagnostic Procedure 203
Component Inspection 205
Removal and Installation 205
DTC P0122, P0123 TP SENSOR 206
Component Description 206
CONSULT-II Reference Value in Data Monitor Mode 206
On Board Diagnosis Logic 206
DTC Confirmation Procedure 207
Wiring Diagram 208
Diagnostic Procedure 209
Component Inspection 211
Removal and Installation 211
DTC P0125 ECT SENSOR 212
Description 212
On Board Diagnosis Logic 212
DTC Confirmation Procedure 213
Diagnostic Procedure 213
Component Inspection 214
Removal and Installation 214
DTC P0127 IAT SENSOR 215
Component Description 215
On Board Diagnosis Logic 215
DTC Confirmation Procedure 216
Diagnostic Procedure 216

AMOSTRA GRATUITA

automotor.com.br ? Compre o manual completo para acessar todo o conteúdo.